

Mobily FOTA 測試方式 (with our DM server)

=====

◎ FOTA SERVER

1. 使用ftp上傳ipk至 dm:gemtek0978@192.168.5.100
2. ssh dm@192.168.5.100 (pwd:gemtek0978)
3. su (pwd:gemtek0978)
4. cp /home/dm/mobily-all-shell_xx.xx.xx.xxx_arm.ipk /var/www/fota/FW/
5. Modify /var/www/fota/Packages
ServerVersion=xx.xx.xx.xxx (修改為該fw版號)
6. Modify /var/www/fota/updatePKG.php
line2: \$filename = "FW/mobily-all-shell_xx.xx.xx.xxx_arm.ipk";

◎ UI

1. UI 設定 url = http://192.168.5.100/fota/
updateVER.php
interval.init = 3
interval.wait = 3
interval.check = 60